


4. Connection Illustration


Portable DVR Connection

External Display Connection

Installation 1




Installation 2



(3)


BU-18 CCD Camera in Button Design Quick Guide



Law Enforcement Products Manufacturer
LawMate

V1.1

1. Name and Parts



2. Package Contents



NOTE:
Camera is not originally screwed with covert button head in the package.
Remember to screw covert button head before use.



(1)



(2)

3. Application

A. Camera connects to a portable DVR:

1. Install the device same as Installation 1.
2. Insert AV jack into A/V IN DC 5V OUT socket of the portable DVR device.
3. Press portable DVR POWER-ON button for 3 seconds and release the button. Note that HOLD button should switch to off position when POWER button is pressed.
4. A green light will turn on to show that DVR device is turn-on properly.
5. Press REC button to start recording.
6. Captured images are shown on LCD display.
7. Audio and video signals are collected and recorded on DVR.

B. Camera connects to external display device:

1. Install the device same as Installation 2.
2. Slide the back cover of battery holder opened, Insert the battery PP3 (9V) in proper direction. Switch to ON indication.
3. The yellow and white color cable heads are to connect with the external display device (TV or LCD monitor).
4. Connects camera to the battery holder.
5. Captured images are shown on the connected external display device.
6. Noted that external display device is required to connect recording device in order to record motion picture.